

BEDNET[®] SUV & CROSSOVER BULKHEAD NET

BN-0345

INSTRUCTIONS

1. Unpack Bednet[®].
2. Remove net from bag and lay out on rear seat with the Bednet[®] logo and buckles facing up.
3. Take the male end of the seatbelt style buckle and feed it underneath and through the assist handle from outside in. Click it into nearest seatbelt style buckle on the net. Repeat on other side.
4. Using the loose ends, tighten each side to form a straight line at the top of the net. The straps should rest against the front of the assist handle and the rubber label should be centered.
5. With cam strap in hand, locate the forward outer seat post under the rear seat. Feed the tail of the strap around the post from outside in. If the seat post is not exposed, the seat bracket can be used.
7. Drape the bulkhead to the floor. Feed the tail of the strap through appropriate grommet.
8. Feed the tail through the cam buckle and pull most of the slack out. Rotate the cam buckle under the seat away from vehicle fabric, and tighten until the net is taut. Repeat on other side.
9. Make final adjustments at the top of the net to make sure net is centered.
10. Use with or without rear seats down.

WARNING

The attachment of this product is critical and beyond the control of Bednet[®]. Bednet[®] is neither responsible for the attachment nor the installation. Failure to use this product properly may cause product not to operate as intended and reduce its effectiveness at protecting driver and front seat passenger. Never use this product for lifting, towing or personal restraint.

For technical information or other questions regarding our products, call toll free 1-866-423-3638 or visit us online at www.thebednet.com.