

# BEDNET<sup>®</sup> STAKE TRUCK NET

BN-0711, BN-0713

## INSTRUCTIONS

1. Unpack Bednet<sup>®</sup>.
2. Drape the Bednet<sup>®</sup> over your load with the label facing up and positioned at the rear of the truck bed. Mesh should be below webbing.
3. Using the six (three per side) adjustable cam straps, attach flat hooks to rub rails or box frame and tighten evenly and securely.
4. Recheck straps to ensure security.

## WARNING

The attachment of this product is critical and beyond the control of Bednet<sup>®</sup>. Bednet<sup>®</sup> is NOT responsible for the attachment nor the installation. It neither guarantees, nor will it be liable for any damage resulting from the use of this product. Failure to use this product properly may cause cargo to shift or drop from the vehicle which may result in substantial property damage and or serious personal injury or death. Never use this product for lifting, towing or personal restraint. Do not use this product if hardware is defective, webbing is cut, frayed, exposed to extreme heat, burned, melted or abraded. This product was not designed to secure transportation of items or articles which are small enough to escape the restraint system. Do not exceed working load limit of 835 lbs. or minimum working load of anchor points to which this product is attached or product used to secure. Check your load and this product after first 10 miles and frequently thereafter. **READ COMPLETE OPERATING INSTRUCTIONS PRIOR TO USE.**

For technical information or other questions regarding our products, call toll free 1-866-423-3638 or visit us online at [www.theBednet.com](http://www.theBednet.com).